

B&B OFF ROAD CARRY RACK - INSTALLATION GUIDE



Fitting the following Models

Model: CRF300L & Rally Year: 2021-2023
Following Parts Supplied -

- 1) Carry Rack (polished or black)
- 2) M8 x 80 Countersunk Bolt
- 2) M8 x 45 Cap Bolt
- 2) M8 Washers
- 2) 23mm Long Flat Spacers
- 2) Stepped Spacers

Step 1 - Remove the stock protruding seat bolts and bushes. These will not be needed for the rack installation

Step 2 - Remove the rear tie point bolts - keeping the bushes handy.

Step 3 - Insert the supplied stepped spacers into the seat mounts and slide the rack into position on the outside of each spacer. Insert the countersunk bolts and tighten a few threads to hold the rack in place.

Step 4 - Reinsert the genuine rear bushes removed previously and slide the supplied flat spacers between the bush and carry rack mount. Use the left over cap bolt and washer to secure.

Step 5 - Tighten all bolts gradually and you will be ready to load.

